
Service Manua

Black and White Television with Radio & Digital Clock

Chassis No. 1E01-A Main Manual



Specifications:

Television

Power Source:

Power Consumption

Aerial

impedance: Antenna

120V, 220V~240V, 50Hz

DC: 6V

4.4W AC:

DC: 1.8W

UHF/VHF/FM Monopole Aerial (Antenna), 75Ω .

Unbalanced type.

UHF/VHF External Aerial

(Antenna). 75 Ω , Unbalanced type.

Receiving Channel:

U.S.A. CCIR B&G U.K.

VHF: UHF:

2-13 2-12 14-83 21-69

21-69

Intermediate

Frequency:

Video: 38.9MHz

Sound:

34.4MHz (USA Standard)

33.4MHz (CCIR Standard)

32.9MHz (U K Standard)

Integrated Circuits:

12 lc's

Semiconductor: (With Radio)

21 Transistors 42 Diodes

Nominal Anode Voltage:

Picture Tube: Speaker:

Automatic Circuit:

4.7 KV (Zero Beam Current) 40CB4 1.5" 36° Deflection 2.8cm, 16Ω , Round type Peak Automatic Gain Control Saw-Tooth Automatic Frequency

Control

Automatic Voltage Regulator

Height:

40mm Width:

Depth:

135mm 166mm

Weight: 0.83kg

Radio

Dimensions:

Radio Frequency

Range: Audio Output: AM:

525-1605kHz 88-108MHz

FM:

0.1W

Specifications are subject to change without notice.



Matsushita Electric Trading Co., Ltd. P.O. Box 288, Central Osaka Japan CODE NO. FTD8001-030

CAUTION

The high voltage supply at the picture tube anode will give an unpleasant shock, but does not supply enough current to give a fatal burn or shock.

However, secondary human reaction to otherwise harmless shocks have been known to cause injury. Always discharge the picture tube anode to the receiver chassis before handling the tube.

Certain portions of the high voltage generating circuit are dangerous and extreme caution should be observed. The picture tube is highly evacuated and, if broken, glass fragments will be violently expelled.

WHEN HANDLING THE PICTURE TUBE, ALWAYS WEAR GOGGLES AND PROTECTIVE CLOTHING.

The electrical parts used in this model such as the resistors, the capacitors and the transistors, are smaller than the same parts used in conventional models. Very painstaking and careful servicing techniques, therefore, are necessary for this model.

VORSICHT

Die Hochspannung der Bildröhrenanode genügt für einen unangenehmen Schlag, ist aber nicht hoch genug um Verbrennungen oder tödliche Schläge zu bewirken. Sekundäre Verletzungen als Folge harmloser Schläge sind jedoch vorgekommen. Vor Hantieren an der Bildröhre sollte daher die Anode längere Zeit über einen Widerstand von 100K Ohm zum Chassis entladen werden.

Gewisse Abschnitte des Hochspannungskreises sind gefährlich; äusserste Vorsicht ist angebracht. Die Bildröhre steht unter Hochvakuum: beim Zerbrechen werden Glasstücke gefährlich umherfliegen.

BEIM HANTIEREN DER BILDRÖHRE IMMER SCHUTZ-BRILLE UND HANDSCHUHE TRAGEN!

Die elektrischen Teile dieses Modells wie Widerstände, Kondensatoren und Transistoren sind kleiner als die gleichen Teile bei herkömmlichen Geräten. Sehr vorsichtige und sorgfältige Arbeit ist daher bei den Servicearbeiten an diesem Modell erforderlich.


DISASSEMBLY INSTRUCTIONS—DEMONTAGE ANLEITUNG—

UPPER CABINET REMOVAL

- 1. Remove 2 screws (a) and 2 screws (b) as shown in Fig. 1, 2.
- 2. Lift up upper cabinet as shown the arrow in Fig. 2.

Abnahme der Gehäuse-Oberseite

- 1. Entfernen Sie die in Abb. 1 und 2 gezeigten zwei Schrauben A und B.
- 2. Heben Sie die Gehäuseoberseite in Pfeilrichtung, wie in Abb. 2 gezeigt.






Fig. 2

Abb. 2

CLOCK P.C.B. REMOVAL

Remove screw © as shown in Fig. 3.

RADIO BLOCK REMOVAL

Remove 2 screws (1) as shown in Fig. 3.

ESCUTCHEON BLOCK REMOVAL

1. Pull the escutcheon block out of the cabinet as shown the arrow in Fig. 4.

CRT REMOVAL

- 1. Remove clock P.C.B., radio block and escutcheon block.
- 2. Pull the CRT as shown in Fig. 5.

MAIN PCB REMOVAL

- 1. Remove 3 knobs barriers (E) as shown in Fig. 6.
- 2. Pull out 6 knobs (F).
- 3. Lift up the main PCB by screw driver as shown in Fig. 6 and then pull it towards you.




Fig. 3 Abb. 3




Fig. 5 Abb. 5

Uhren-Leiterplatten-Ausbau

Entfernen Sie die in Abb. 3 gezeigte Schraube C.

Radioblock-Ausbau

Entfernen Sie die beiden in Abb. 3 gezeigten Schrauben D.

Plattenblock-Ausbau

 Ziehen Sie den Plattenblock in der in Abb. 4 gezeigten Pfeilrichtung aus dem Gehäuse.

Ausbau der Kathodenstrahlröhre

- Bauen Sie die Uhren-Leiterplatte sowie den Radio- und Plattenblock aus.
- 2. Ziehen Sie die Kathodenstrahlröhre wie in Abb. 5 gezeigt.

Haupt-Leiterplatten-Ausbau

- 1. Entfernen Sie die drei in Abb. 6 gezeigten Knopfsperren E.
- 2. Ziehen Sie die sechs Knöpfe F heraus.
- 3. Heben Sie die Haupt-Leiterplatte wie in Abb. 6 gezeigt mit einem Schraubenzieher an und ziehen Sie sie auf sich zu.





Fig. 4 Abb. 4



HOW TO REPLACE CHIPS (RESISTOR, CAPACITOR, JUMPER)


- 1. Remove solder from chip by using solder sucker.
- 2. Remove chip with tweezers by rotating it while removing solder as shown in Fig. 7.
- 3. Solder circuit board first and then solder chip in the direction of the arrow as shown in Fig. 8.

Notes:

- 1. Do not use chip again which is removed from P.C. Board.
- 2. Use lead wire with insulator for replacement instead of chip jumper.

NOTE FOR REPLACING CHIPS

- 1. Do not heat chips more than three (3) seconds.
- 2. Be careful not to damage the electrode of chips.
- 3. Use soldering iron (less than 60 W) and tweezers for replacing chips.



AC Adaptor Operation

Make sure to set the voltage selector of the AC adaptor to correct voltage in your area. If it is not set to the correct voltage in your area, reset to voltage with a screw driver as shown in Fig. 9.

Voltage in your area

Voltage selector position

110V, 120V →

120V

220V, 240V →

220V

Dry Battery Operation

Insert 4 "AA" size dry batteries to the battery case (including) as shown in Fig. 10.




Fig. 9

Abb. 9

Chip-Austausch

(Widerstände, Kondensatore, Schaltdraht)


- 1. Entfernen Sie das Lötmetall mit einem Lotsauger.
- 2. Entfernen Sie das Chip mit einer Pinzette durch Drehen, während das Lötmetall wie in Abb. 7 gezeigt, entfernt wird.
- 3. Löten Sie zuerst die Leiterplatte und dann das Chip in der in Abb. 8 gezeigten Pfeilrichtung.

Hinweise:

- 1. Das von der Leiterplatte entfernte Chip kann nicht wiederverwendet werden.
- 2. Verwenden Sie als Ersatz für den Chip-Schaltdraht einen isolierten Leitungsdraht.

Hinweis für Chip-Austausch

- 1. Erhitzen Sie die Chips nicht länger als 3 Sekunden.
- Achten Sie darauf, daß die Chipelektrode nicht beschädigt wird.
- 3. Verwenden Sie einen Lötkolben (weniger als 60 W) und Pinzette für den Chip-Austausch.



Wechselstrom-Adapter-Betrieb

Achten Sie darauf, daß der Spannungswähler des Wechselstrom-Adapters auf die richtige Spannung an Ihrem Ort eingestellt ist. Wenn die Einstellung nicht richtig ist, muß die Spannung wie in Abb. 9 gezeigt mit einem Schraubenzieher entsprechend eingestellt werden.

Örtliche Spannung Spannungswähler-Stellung
110 V , 120 V → 120 V

220 V, 240 V → 220 V

Trockenbatterie-Betrieb

Legen Sie vier "AA" Trockenbatterien in das Batteriefach (eingeschlossen) wie in Abb. 10 gezeigt.




Fig. 10 Abb. 10

Rechargeable Battery Operation (TY-375)

To obtain maximum playing time, charge new battery for 8 hours before using. For best battery life, it is recommended to recharge the battery after each use. Recommended charging time is 4 hours charge for 1 hour of use. (8 hours charge after 2 hours of battery operation.) To attain maximum battery life, the TV set should not be operated more than 2 hours without recharging the battery. And for best battery life, batteries should not be charged more than is necessary.


Betrieb mit aufladbaren Batterien (TY-375)

Laden Sie die neue Batterie 8 Stunden vor der Benutzung, um eine möglichst lange Spielzeit zu erhalten. Zur Verlängerung der Batterielebensdauer empfiehlt es sich, die Batterie nach jedem Gebrauch aufzuladen. Die empfohlene Aufladezeit beträgt vier Stunden für eine Stunde Betriebszeit. (Acht Stunden Aufladezeit bei zwei Stunden Batteriebetrieb.) Für max. Batterielebensdauer empfiehlt es sich, das Fernsehgerät nicht länger als zwei Stunden ohne Nachladen der Batterie zu betreiben und die Batterie nicht zu überladen.

DIAL STRINGING

TV BLOCK

- 1. Turn the TV tuning shaft fully clockwise.
- 2. Follow steps ① to ③ for correct stringing as shown in Fig. 12.
- 3. Wind the dial string to the tention roller (A) several turns, then turn the tention roller (B) counterclockwise seven times for getting appropriate tention.
- 4. Fix the dial string on the Tention roller (A) and TV pulley with bond as shown in Fig. 11.
- 5. Insert the tention roller (B) to groove on the TV bracket as shown in Fig. 12.
- 6. Mount the TV tuning knob and turn it fully counterclockwise.
- 7. Mount the TV Dial pointer at the start point on the TV bracket as shown in Fig. 13.
- 8. Fix the TV dial pointer on the string with bond as shown in Fig. 14.






Fig. 12


Abb. 12

Fernsehblock

1. Drehen Sie die Fernseh-Abstimmwelle ganz im Uhrzeigersinn.

SKALENSCHNUR -

- 2. Gehen Sie für richtige Schnuranbringung entsprechend den in Abb. 12 gezeigten Schritten 1 bis 3 vor.
- 3. Wickeln Sie die Skalenschnur mehrmals um die Spannrolle A und drehen Sie dann die Spannrolle B sieben Mal entgegen dem Uhrzeigersinn, um die richtige Spannung zu erhalten.
- Kleben Sie die Skalenschnur an der Spannrolle A sowie an der Fernsehtreibrolle mit Kleber an, wie in Abb. 11 gezeigt.
- 5. Schieben Sie die Spannrolle B in die Ausnehmung der Fernsehstütze, wie in Abb. 12 gezeigt.
- 6. Bringen Sie den Fernsehabstimmknopf an und drehen Sie ihn voll entgegen dem Uhrzeigersinn.
- Bringen Sie den Fernsehskalenzeiger am Startpunkt der Fernsehstütze an, wie in Abb. 13 gezeigt.
- 8. Kleben Sie den Fernsehskalenzeiger auf der Schnur, wie in Abb. 14 gezeigt, mit Kleber an.







Fig. 14

Abb. 14


RADIO BLOCK


- 1. Turn the pulley fully clockwise.
- 2. Follow the steps ① to ⑥ for correct stringing as shown in Fig. 16.
- 3. Mount the Radio tuning knob and turn it fully counterclockwise.
- 4. Mount the Radio Dial pointer at the start point on the Radio bracket as shown in Fig. 17.
- 5. Fix the Radio dial pointer on the string with bond as shown in Fig. 18.



Radioblock

- 1. Drehen Sie die Treibrolle voll im Uhrzeigersinn.
- 2. Gehen Sie für die richtige Schnuranbringung entsprechend den in Abb. 16 gezeigten Schritten 1 bis 6 vor.
- Bringen Sie den Radioabstimmknopf an und drehen Sie in voll entgegen dem Uhrzeigersinn.
- 4. Bringen Sie den Radioskalenzeiger am Startpunkt der Radiostütze, wie in Abb. 17 gezeigt, an.
- Kleben Sie den Radioskalenzeiger auf der Schnur, wie in Abb. 18 gezeigt, mit Kleber an.






TELEVISION INDICATOR ALIGNMENT

TELEVISION INDICATOR ALIGNMENT

- 1. Set the function selector to TV position and set the band selector to UHF position.
- 2. Set the system switch to USA position.
- 3. Set the pointer to the station of which is the lowest receivable channel in your area.
- 4. Adjust VR92 to get the best picture.
- 5. Set the pointer to the station of which is the highest receivable channel in your area.
- 6. Adjust VR93 to get the best picture.
- 7. Set the pointer same as step 3.
- 8. Readjust VR92 if necessary.
- 9. Set the band selector to VHF position.
- 10. Set the pointer to the station of which is the lowest receivable channel in your area.
- 11. Adjust the VR94 to get the best picture.
- 12. Set the pointer to the station of which is the highest receivable channel in your area.
- 13. Adjust the VR96 to get the best picture.

Fernsehanzeige-Einstellung

- 1. Stellen Sie den Betriebswahlschalter auf die Stellung "TV" und den Bandwähler auf UHF.
- 2. Stellen Sie den Systemschalter auf USA.
- 3. Stellen Sie den Zeiger auf den Sender mit dem niedrigsten noch empfangbaren Kanal Ihres Ortes ein.
- 4. Stellen Sie den VR92 auf das beste Bild ein.
- 5. Stellen Sie den Zeiger auf den Sender mit dem höchsten noch empfangbaren Kanal Ihres Ortes ein.
- 6. Stellen Sie den VR93 auf das beste Bild ein.
- 7. Stellen Sie den Zeiger wie bei Pos. 3 ein.
- 8. Stellen Sie, falls erforderlicch, den VR92 nach.
- 9. Stellen Sie den Bandwähler auf VHF.
- 10. Stellen Sie den Zeiger auf den Sender mit dem niedrigsten noch empfangbaren Sender Ihres ortes ein.
- 11. Stellen Sie den VR94 auf das beste Bild ein.
- 12. Stellen Sie den Zeiger auf den Sender mit den höchsten noch empfangbaren Sender Ihres Ortes ein.
- 13. Stellen Sie den VR96 auf das beste Bild ein.



- ADJUSTMENTS -

AVR (AUTOMATIC VOLTAGE REGULATOR)

Connect a voltmeter across TP91 and ground. Make certain the B+ supply voltage is $+4.8V \pm 0.05V$. Adjust the AVR control VR71 if necessary.

YOKE POSITION

The yoke is secured to the neck of the picture tube with a angular clamp and screw. To Adjust the yoke and correct for picture tilt: Loosen the clamp screw, correct tilt, and retighten the clamp screw.

CENTERING

The picture centering device consists of two rings located at the rear of the yoke assembly. Each ring has a tab for ease of adjustment.

The tabs should be rotated and moved towards or away from each other until the picture is properly centered on the picture tube screen.

TO ADJUST THE R-F AGC PROPERLY

- 1. Tune in strong local station.
- 2. Turn the R-F AGC control VR19 fully counterclockwise.
- 3. Observe the input signal, turn the R-F AGC control VR19 clockwise to the point where the snow noise disappears in the picture.
- 4. Check the reception with all channels. If the set does not get, clear picture on all channels.

VERTICAL HEIGHT

Adjust the V-Height control VR32 until picture becomes from top to bottonm.

-ABSTIMMUNGEN

AVR (AUTOMATISCHER SPANNUNGS-REGLER)

Einen Spannungsmesser über TP91 anschließen und erden. Sicherstellen, daß die B+ Versorgungsspannung +4.8V ± 0.05V beträgt. Den automatischen Spannungsregler erforderlichenfalls neueinstellen.

POSITION DES ABLENKJOCHS

Das Ablenkjoch ist mit Hilfe einer Winkelschelle und Schraube am Hals der Bildröhre befestigt. Um das Ablenkjoch einzustellen und eine Korrektur der Bildlage vorzunehmen, muß die Klemmschraube gelöst und nach vorgenommener Korrektur wieder festgezogen werden.

ZENTRIEREN

Die Bildzentrierungseinheit besteht aus zwei Ringen, die sich am Ende der Ablenkjocheinheit befinden. Jeder Ring weist einen Streifen zum Vereinfachen der Einstellung auf.

Die Streifen sind durch Drehen zu- oder voneinander zu bewegen, bis sich das Bild genau in der Bildröhrenmitte befindet.

RICHTIGE EINSTELLUNG DER HF-SCHWUNDAUSGLEICHAUTOMATIK (AGC)

- 1. Einen starken Ortssender einstellen.
- 2. Den HF-AGC-Regler VR19 bis zum Anschlag entgegen dem Uhrzeigersinn drehen.
- 3. Den Bildschirm beobachten und den HF-AGC-Regler VR19 im Uhrzeigersinn drehen, bis das Bild schneefrei d.h. ohne weiße Flecken ist.
- 4. Den Empfang auf allen Kanälen überprüfen, falls das Bild nicht klar ist.

BILDHÖHE

Den Bildhöhenregler VR32 drehen, bis das Bild den ganzen




Fig. 21

Abb. 21

ALIGNMENT OF RADIO

AM I-F & R-F ALIGNMENT (Equipment Required: Signal Generator, 16 ohm speaker or dummy load, output meter.)

Output of signal generator should be no higher than necessary to obtain an output reading. Maintain line voltage at 220 ~ 240 volts. Set Volume control to maximum. Set selector to AM **RADIO** SIGNAL · SIGNAL **REMARKS GENERATOR** DIAL CONNECT **ADJUST GENERATOR FREQUENCY SETTING** COUPLING 455 kHz Point of non-1 L1110 (30% Mod. with interference 400 Hz) (on/about L1111 600 kHz). Fashion loop of several Output meter 600 kHz turns of wire and 2 Adjust for maximum output. L1101 (OSC coil) Marked across L1100 (ANT coil) Repeat steps (2) and (3). radiate signal into loop (30% Mod. with 600 kHz 400 Hz) earphone jack. of receiver. (O) (OSC trim-1400 kHz mer) Marked (30% Mod. with (A) (ANT trim-1400 kHz 3 400 Hz) mer)

Note: 1. Cement antenna coil with wax after completing alignment.

2. Make certain that speaker or dummy resistor (16 Ω) is connected to the earphone jack when aligning.

Poly, variable capacitor

Fig. 22

00 0 FC2 O

FM I-F ALIGNMENT

(Bar antenna side)

EQUIPMENT REQUIRED

Signal generator that provides 10.7 MHz marker.

Sweep generator that provides 10.7 MHz and 400 kHz sweep width.

OSCILLOSCOPE

Set sweep selector of oscilloscope to EXTERNAL SWEEP.

Apply 50 Hz sweep signal from sweep generator to horizontal input terminals of oscilloscope.

Set selector to FM.

Set Volume control to minimum.

Maintain line voltage at 220 \sim 240 volts.

	Mairitairi	Waintain tine vortage at 225 2 ve vera.										
	SWEEP GENERATOR COUPLING	SIGNAL GENERATOR FREQUENCY	RADIO DIAL SETTING	CONNECT	AD- JUST	WAVE FORM	REMARKS					
1	Connect to TP102 through FM DUMMY. Common to chassis $0.1\mu F 10K\Omega$ $75\Omega \rightleftharpoons 0.7\mu F 10K\Omega$		Point of non- interference	Connect vert.	L1006 L1007		Adjust for maximum amplitude and proper linearity.					
2	75Ω To TP106	10.7 MHz	(on/about 90 MHz).	TP103. Common to chassis.	L1008	10.7MHz	Adjust for proper linearity.					

EM R.E ALIGNMENT (Equipment Required: Signal Generator)

EI	W R-F ALIGNWENT (Equipment required, Signal delicition)											
	SIGNAL GENERATOR COUPLING	SIGNAL GENERATOR FREQUENCY	RADIO DIAL SETTING	CONNECT	ADJUST	REMARKS						
3	Connect to EXT FMantenna terminal through FM dummy antenna. Common to chassis.	90 MHz (30% Mod. with 400 Hz)		Output meter across earphone	L1005 (FM OSC coil) L1004 (FM collector coil)	Adjust for maximum output.						
4	0.1μF To EXT FM antenna terminal	106 MHz (30% Mod. with 400 Hz)	Marked 106 MHz	Jack	FC1 (FM OSC trimmer) FC2 (FM collector trimmer)	Repeat step (3) and (4).						

EINSTEIIEN DES RADIOS

AM-ZF- & HF-ABGLEICH (Benötigte Geräte: Prüfgenerator; 16Ω Lautsprecher oder Blindwiderstand, ausgangsmesser.)

Die Ausgangsleistung vom Prüfgenerator sollte nicht höher sein, als zur Erzielung einer Ausgangsanzeige nötig ist.

Den Lautstärkeregler in ganz aufdrehen.

Den wahlschalter in die "AM"-Position stellen.

Die Netzspannung auf 220~240 V konstant halten.

	PRÜF- GENERATOR- ANKOPPELUNG	PRÜF- GENERATOR- FREQUENZ	RADIO- SKALEN- EINSTELLUNG	ANSCHLUSS	ABSTIMMUNG	BEMERKUNGEN					
1	Vinnganaratar	455 kHz (30% Mod. mit 400 Hz)	Störungsfreie Einstellung (auf/um 600 kHz)		L1110 L1111	Auf maximalen					
2	Kippgenerator strahlt Ausgangssignal an Schleifenantenne aus.			Ausgangsmes- ser parallel an Ohrhörer Buchse.	L1101 (Schwing-spule) L1100 (Antennen-spule)	Ausgang abstimmen. Schritte (2) und (3) wiederholen.					
3		1400 kHz (30% Mod. mit 400 Hz)	1400 kHz		(O) (Schwing-trimmer) (A) (Antennen-trimmer)	(e) Wedernelen.					

Anmerkungen: 1. Die Antennenspule nach Beenden des Abgleichs mit Wachs verkleben.

2. Sicherstellen, daß der Lautsprecher oder Blindwiderstand (16 Ω) beim Abgleich an die Ohrhörer-Buchse angeschlossen ist.

Poly-drehkondensator

Abb. 22



UKW-ZF-ABGLEICH

Stabantennenseite

BENÖTIGTE GERÄTE

Prüfgenerator, der 10.7 MHz-Markierer aufweist.

Kippgenerator, der 10.7 MHz und 400 kHz Kippbreite aufweist.

OSZILLOSGRAPH

Den Kipp-Wahlschalter am Oszillograph auf EXTERNAL SWEEP einstellen.

50 Hz-Kippsignal vom Kippgenerator den horizontalen Eingangsanschlüsse des Oszillograph zuleiten.

Den Wahlschalter auf FM stellen.

Den Lautstärkeregler in die Minimum Position stellen.

Die Netzspannung auf 220~240 V konstant halten.

	· · · · · · · · · · · · · · · · · · ·								
	KIPP- GENERATOR- ANKOPPELUNG	PRÜF- GENERATOR- FREQUENZ	RADIO- SKALEN- EINSTELLUNG	ANSCHLUSS	ABSTIM- MUNG	WELLEN- FORM	BEMERKUNGEN		
1	Über UKW-Ersatzantenne an TP102 anschließen Anschluß an Chassiserdung.	10.7 MHz	Störungsfreie Einstellung.	Vert. Verst. des Oszillgraph an TP103.	L1006 L1007		Auf maximale Amplitude und saubere Liniariät abstimmen.		
2	75Ω \$ 0.1μF 10KΩ To TP106 Über UKW	·	(um/aug 90 MHz)	—Anschluß an Chassiserdung.	L1008	10.7MHz	Zur Erzielung sau berer Linearität		

UKW-HF-ABGLEICH

	PRÜF- GENERATOR- ANKOPPELUNG	PRÜF- GENERATOR- FREQUENZ	RADIO- SKALEN- EINSTELLUNG	ANSCHLUSS	ABSTIMMUNG	BEMERKUNGEN
3	EXT UKW-Antennen- anschluß über UKW- Ersatzantenne anschlie- ßen — Anschluß an chassiserdung.	90 MHz (30% Mod. mit 400 Hz)	90 MHz	Ausgangsmesser parallel an	L1005 (FM UKW-Schwing spule) L1004 (UKW- Kollektorspule)	Auf maximalen Ausgang
4	0.1μF Zu FM- Außenantennen- Anschluß	106 MHz (30% Mod. mit 400 Hz)	106 MHz	Ohrhörer Buchse.	FC1 (UKW- Schwing-trimmer) FC2 (UKW- Kollektor-trimmer)	abstimmen. Schritte (3) und (4) wiederholen.

- 9 -


TIMER ALARM CIRCUIT

Normal Use (SW4 OFF)

- 1. When the power switch is pushed to the ON position, a voltage is applied to the base of Q301 through R1301 and C1302 to bias Q301 in the forward direction so that Q301 is energized and its collector voltage falls.
- 2. NAND gates 1 and 2 form a flip-flop circuit, whose terminal S goes low so that output Q goes high. \overline{Q} goes low.
- 3. C1302 is charged increasingly with time until it is fully charged. Q301 becomes independent of the subsequent operations.
- 4. As output Q is at high level, the base voltages of Q302 and Q303 rise to energize these transistors.
- 5. The output of Q303 is applied to the base of Q71 through C704 and D76 (which is provided for preventing reverse current flow) to energize the transistor.
- 6. Since Q302 is also energized, Q72 and Q73 become energized so that the AVR circuit starts operating to drive the circuits of the TV and radio.
- 7. Since output Q is at low level, the base voltage of Q304 falls to energize it. As a result, a voltage is applied to the base of Q74 to energize the transistor, thus operating the low-frequency output circuit.
- 8. As switch 4 is open, the input level of inverter 4 goes high so that the inverter output goes low. This inverter output makes one of the terminals of NAND gate 3 low so that the output of NAND gate 3 goes high. Thus NAND gate 2 will not be reset.

Note:

The switches are function switches, which are closed (ON) when at ALARM, or open (OFF) at other positions. H signifies high; and L, low.




TV/Radio Timer (SW4 ON)

- 1. When SW4 is pushed to the ON position, input to inverter 4 goes low and its output goes high. This output is applied to one terminal of NAND gate 3.
- 2. Since C1303 has already been charged by R1312, the other terminal of NAND gate 3 goes high, and the output of NAND gate 3 goes low. This makes terminal R of NAND gate 2 low so that this reset-set flip-flop circuit's output condition is reversed. That is, output \overline{Q} goes low, and output Q goes high.
- 3. Q303, Q302 and Q304 all become deenergized so that the low-frequency output circuit of the TV/radio will not operate.
- 4. This is a standby state, which is maintained until an alarm signal (negative pulse) is inputted to the clock input terminal from the clock circuit.
- 5. When the input pulse is applied to the clock input terminal, terminal S goes low at the decay portion of the first pulse so that the output of the flip-flop circuit is reversed. Thus output \overline{Q} goes high and output \overline{Q} goes low to drive each circuit.


H J CON ON ON SW4

Alarm Operation

- 1. Keep switch 4 in the ON position.
- When an alarm signal is applied from the clock circuit, C1303 discharges through diode D304 to make one of the input terminals of NAND gate 3 low.
 Therefore, the output of NAND gate 3 goes high, and the output of the flip-flop circuit remains unchanged.
- 3. The output of inverter 4 is at high level at this time, and is applied to D301 through R1313. D301 is energized when the alarm signal is at low level. This change is fed to the low-frequency output to produce the alarm sound from the speaker.



- 4. Output Q from the reset-set flip-flop circuit is at high level at this time, but the base voltage of Q302 is lowered by D305 and switch 4 to deenergize it after output Q runs through R1306.
 - So that AVR circuit still does not start operating thus does not operate circuits of the TV and Radio.
- 5. After one minute of alarm output signals, C1303 becomes charged again through R1312 so that the input terminals of NAND gate 3 go high.
- 6. As switch 4 is in the ON position, the output of inverter 4 goes high, and both inputs to the NAND gate are at high level so that its outputs go low.
- 7. Thus terminal R goes low, and the output of the reset-set flip-flop circuit changes to open the low-frequency output circuit. Thus the timer alarm circuit returns to the standby condition.



Note: 1. The chirp alarm sound will stop automatically within one minute.

After stop the chirp sound, the receiver works into the wake-up operation again.

2. After set the FUNCTION switch to "ALARM" position (include wake-up operation), wish to enjoy TV or radio program, set the volume control to stand-by position and the FUNCTION switch to UHF or VHF position then turn the receiver on again.

SCHALTUHRALARMSCHALTUNG


Normale Verwendung (SW4 Aus)

- Beim Drücken des Netzschalters auf ON (Ein) wird der Basis von Q301 über R1301 und C1302 eine Spannung zugeleitet, um Q301 in Vorwärtsrichtnng zu betreiben, so daß Q301 einge schaltet wird und dessen Kollektorspannung abfällt.
- 2. Die NICHT-UND-Glieder 1 und 2 bilden eine Flip-Flop-Schaltung, deren Klemme S niederpegelig, um den Ausgang Q hochpegelig zu machen. \overline{Q} wird niederpegelig.
- 3. C1302 wird allmählich ganz aufgeladen. Q301 wird durch die folgenden Vorgänge nicht mehr beeinflußt.
- 4. Da der Ausgang Q hochpegelig ist, steigen die Basisspannungen von Q302 und Q303 an, um diese Transistoren einzuschalten.
- 5. Der Ausgang von Q303 wird über C704 und D76 (dient zur Verhinderung von Rückwärtsstromfluß) der Basis von Q71 zugeleitet, um den Transistor einzuschalten.
- 6. Da Q302 ebenfalls eingeschaltet ist, werden Q72 und Q73 eingeschaltet, so daß die Spannungsgleichhalterschaltung in Funktion tritt, um die Fernseh- und Radioschaltung zu betreiben.
- 7. Da der Ausgang Q niederpegelig ist, fällt die Basisspannung von Q304 ab, um diesen einzuschalten. Dadurch wird der Basis von Q74 eine Spannung zugeleitet, um den Transistor einzuschalten und somit die Niederfrequenzausgangsschaltung in Betrieb zu setzen.

asisspannungen von Q302 und 6 (dient zur Verhinderung von tet, um den Transistor einzu-

Zur Beachtung:

und L niederpegelig.



Bei den Schaltern handelt es sich um Funktionsschalter, die bei Einstell-

ung auf ALARM geschlossen (Ein)

und bei anderen Stellungen geöffnet

(Aus) sind. H bedeutet hochpegelig


8. Da der Schalter 4 geöffnet ist, wird der Pegel der Umkehrstufe so hoch, daß der Ausgang der Umkehrstufe niederpegelig wird. Durch diesen Ausgang der Umkehrstufe wird eine der Klemmen des NICHT-UND-Glieds 3 niederpegelig um den Ausgang des NICHT-UND-Glieds 3 hochpegelig zu machen. Das NICHT-UND-Glied 2 wird daher nicht zurückgestellt.


• Fernseh-/Radio-Schaltuhr (SW4 Ein)

- Beim Drücken des Schalters SW4 auf ON (Ein) wird der Eingang zur Umkehrstufe 4 niederpegelig und deren Ausgang hochpegelig. Dieser Ausgang wird einer Klemme des NICHT-UND-Glieds 3 zugeleitet.
- 2. Da C1303 bereits durch R1312 aufgeladen worden ist, wird die andere Klemme des NICHT-UND-Glieds 3 hochpegelig und der Ausgang des NICHT-UND-Glieds 3 niederpegelig. Dadurch wird die Klemme R des NICHT-UND-Glieds 2 niederpegelig, so daß der Ausgang dieser Flip-Flop-Schaltung für Einstellung/Rückstellung umgekehrt wird. Der Ausgang Q wird daher niederpegelig und der Ausgang Q hochpegelig.
- 3. Q303, Q302 und Q304 werden eingeschaltet, so daß die Niederfrequenzausgangsschaltung des Fernsehers/Radios nicht funktioniert.
- 4. Hierbei handelt es sich um einen Bereitschaftszustand, der beibehalten wird, bis ein Alarmsignal (negativer Impuls) von der Uhrschaltung der Uhreingangsklemme zugeleitet wird.
- 5. Bei Zuleitung des Eingangsimpulses zur Uhreingangsklemme, wird die Klemme S beim Abklingteil des ersten Impulses niederpegelig, so daß der Ausgang der Flip-Flop-Schaltung umgekehrt wird. Der Ausgang Q wird daher hochpegelig und der Ausgang Q niederpegelig, um die einzelnen Schaltungen zu betreiben.


Alarmbetrieb

- 1. Den Schalter 4 auf ON (Ein) lassen.
- 2. Bei Zuleitung eines Alarmsignals zur Uhrschaltung wird C1303 über die Diode D304 entladen, um eine der Eingangsklemmen des NICHT-UND-Glieds 3 niederpegelig zu machen.
 - Der Ausgang des NICHT-UND-Glieds 3 wird daher hochpegelig und der Ausgang der Flip-Flop-Schaltung bleibt unverändert.





- 3. Der Ausgang der Umkehrstufe 4 ist dabei hochpegelig; er wird über R1313 den Dioden D301 zugeleitet. D301 wird eingeschaltet, wenn das Alarm-signal niederpegelig ist. Diese Änderung wird dem Niederfrequenzausgang zugeleitet, um den Alarmton über den Lautsprecher wiederzugeben.
- 4. Dabei ist der Ausgang Q von der Flip-Flop-Schaltung für Einstellung/Rückstellung hochpegelig, die Basisspannung von Q302 wird jedoch durch D305 und Schalter 4 verringert, um diesen auszuschalten, wenn der Ausgang Q durch R1306 fließt so daß die AVR-Schaltung noch nicht arbeitet und somit nicht die Radio-und Fernsehschaltungen tätig werden.
- 5. Nach einer Minute von Alarmausgangssignalen wird C1303 durch R1312 wieder aufgeladen, so daß die Eingangsklemmen des NICHT-UND-Glieds 3 hochpegelig werden.
- 6. Da sich der Schalter 4 auf ON (Ein) befindet, wird der Ausgang der Umkehrstufe 4 hochpegelig; da beide Eingänge zum NICHT-UND-Glied hochpegelig sind, werden dessen Ausgänge niederpegelig.
- 7. Daher wird die Klemme R niederpegelig und der Ausgang der Ausgangder Flip-Flop-Schaltung für Einstellung/Rückstellung ändert sich, um die Niederfrequenzausgangsschaltung zu öffnen. Auf diese Weise kehrt die Schaltuhralarmschaltung zum Bereitschaftszustand zurück.



Hinweise

- 1. Der Zwitscher-Weckton stoppt automatisch nach einer Minute. Danach schaltet der Empfänger wieder auf Wecken.
- 2. Um ein Fernseh- oder Rundfunkprogramm zu empfangen, zunächst den Funktionsschalter (10) auf ALARM (einschließlich) Wecken stellen, dann den Lautstärkeregler (11) auf Bereitschaftsposition und den Funktionsschalter (10) wieder auf UHF oder VHF stellen. Zum Schluß den Empfänger wieder einschalten.

IN CIRCUIT RESISTANCE

WIDERSTAND IM SCHALTKREIS

									
resistor No.	resistance	resistor No.	resistance	resistor No.	resistance	resistor No.	resistance	resistor No.	resistance
TV		R185	1.1ΚΩ	R360	820Ω	R703	зкΩ	R1050	330KΩ
R88	16ΚΩ	R186	330Ω	R361	56K Ω	R704	470Ω	R1051	1ΚΩ
R89	2.2K Ω	R187	1.4ΚΩ	R401	560Ω	R705	4.7KΩ	R1052	1ΚΩ
R90	16ΚΩ	R188	4.5K Ω	R402	39 Ω	R706	Ω 086	R ₁₀₅₃	330Ω
R91	6.8KΩ	R201	100Ω	R403	10ΚΩ	R.707	10Ω	R1054	360Ω
500	140	5000	5.040	D 404	0.01/0	5710	500	5.4055	
R92	1ΚΩ	R202	5.6K Ω	R404	2.2ΚΩ	R710	50Ω	R1055	330Ω
R93	255ΚΩ	R203	5.6K Ω	R405	27ΚΩ	R711	50Ω	R1056	1ΚΩ
R94	22ΚΩ	R204	5.6K Ω	R406	47Ω	R712	50Ω	R1057	1ΚΩ
R95	8.2ΚΩ	R206	12K Ω	R407	2.7K Ω	R713	50Ω	R1058	10ΚΩ
R96	1ΜΩ			R408	470Ω	R714	50Ω	R1059	39Ω
R97	10ΚΩ	R207	12ΚΩ	R409	140ΚΩ	R715	50Ω	R1060	22140
					3.9KΩ	R716	50Ω		33KΩ
R98	10ΚΩ	R208	12ΚΩ	R440				R1061	43Ω
R99	10ΚΩ	R212	2.7ΚΩ	R441	250ΚΩ		50Ω	R1062	Ω_0
R101	56Ω	R213	31Ω	R442	330KΩ	RADIO	140	R1100	100Ω
R111	Ω 0	R301	15ΚΩ	R443	1 M Ω	R81	1ΚΩ	R1101	620Ω
R141	20ΚΩ	R302	18ΚΩ	R444	4.7ΚΩ	R82	2.2ΚΩ	R1102	680KΩ
R142	10ΚΩ	R303	48ΚΩ	R445	1ΚΩ	R83	7.5K Ω	R1130	1ΚΩ
R143	10ΚΩ	R304	60KΩ	R502	68Ω	R84	7.5KΩ	R1131	10KΩ [.]
R144	1ΚΩ	R305	15K Ω	R504	1.8K Ω	R85	7.5KΩ	R1132	11 KΩ:
R145	330Ω	R306	3 . 9K Ω	R505	47ΚΩ	R86	7.5K Ω	R1133	8.5ΚΩ
				R601	1ΜΩ				
R180	1.2ΚΩ	R307	зкΩ	R602	1.5ΚΩ	R1001	47Ω	R1134	100Ω
R181	17ΚΩ	R308	6.8K Ω	R614	$2.2 \mathrm{M}\Omega$	R1002	68Ω	R1135	4ΚΩ
R182	23ΚΩ	R309	3.5K Ω	R615	1ΜΩ	R1003	100Ω	R1136	18ΚΩ
R183	14ΚΩ	R310	2.7Ω	R701	390Ω	R1004	39K Ω	R1137	33ΚΩ
R184	1ΚΩ	R313	22Ω	R702	3.5K $oldsymbol{\Omega}$	R1005	47Ω	R1138	470Ω

CLOCK					
R1301	1kΩ	R1305	100k Ω	R1311	160kΩ
R1302	200kΩ	R1306	9kΩ	R1312	160kΩ
R1303	220kΩ	R1309	680Ω	R1313	470k Ω
R1304	47k Ω	R1310	90k Ω		-

Note: 1. Set power switch to OFF position.

2. When measure the resistor on the solder circuit board by ohm meter, it indicates difference value depend on the polality. In this case should be read high resistance value.


- Hinweis: 1. Stellen Sie den Betriebsschalter auf AUS (OFF).
 - 2. Wenn Sie den Widerstand auf der Leiterplatte mit einem Ohmmeter messen, wird dieses unterschiedliche Werte entsprechend der Polarität anzeigen. In diesem Fall ist ein hoher Widerstandswert abzulesen.

AREAS MAIN RECEPTION

Broadcasting	SSSSSSSSSSSSSSSSSSSSSSSSSSSSSSSSSSSSSS	WINNINN CCIR B & G standard	
Area			

MPFANGSGEBIETE Übertragungssystem VS-Gebiet IF AM FM IF AM FM 2 MHz 525-1605 kHz 88-108 MHz 2 MHz 525-1605 kHz 88-108 MHz 2 MHz 525-1605 kHz 88-108 MHz	NTSC CAMBODIA KOREA PHILIPINES TAIWAN GUAM SAMOA	
HAUPTEMPFANGSGEBIET nge Übertragungssystem VS-Geb /HF AM FM Jamil AM AM AM FM Jamil AM AM AM AM FM Jamil AM		UNITED ARAB EMIRATES UNITED ARAB REPUBLIC UGANDA YEMEN ARAB REPUBLIC YEMEN DEMOCRATIC DEMOCRATIC REPUBLIC ZAIRE
Frequency Range VHF USA 54.88 MHz EUR 47.68 MHz EUR 174.230 MHz U.K.	CCIR FINLAND GERMANY NORWAY YUGOSLAVIA	N RHODESIA SIERRA LEONE SINGAPORE ON SUDAN A SAUDI ARABIA SIA SYRIAN ARAB IUS REPUBLIC A THAILAND A TURKEY AN TURKEY
	U.K. UNITED KINGDOM HONG KONG	ALGERIA JORDAN BAHREIN KENYA BANGLAA-DESH KUWAIT CANARY LEBANON ETHIOPIA LIBERIA GIBRATTAR MALAYSIA INDONESIA MAURTIUS INDIA NIGERIA IRAN QUATAR
Selector position USA EUR	CCIR AUSTRIA BELGIUM CYPRUS DENMARK GREECE ICELAND ITALY MALTY MALTY MALTA NETHERLAND PORTUGAL SPAIN SWEDEN SWEDEN SWEDEN SWITZERLAND	CCIR ALGER BAHRI BANGI CANAF CANAF GIBRA GIBRA INDON INDIA IRAD
RECEPTION AREAS ing system VS Area Broadcasting MTSC (USA) standard CCIR B & G standard U.K. standard		9
MAIN RECEPTION Broadcasting system VS Area Area Broadcasting SERVER OF STAND S	NTSC ARUBA BERMUDA BERMUDA BERNICA CHILE COLOMBIA COSTA RICA CUBA CURACAO	DOMINICAN REP ECUADOR EL SALVADOR GUATEMALA HAITI HONDURAS MEXICO NICARAGUA PANAMA PERU PUENTO RICO SURINAM TRINIDAD & TOBACO USA

— 15 **—**



AGC Bv 1.0-3.5V 4.5V

7 Bu 4.5V

Bs VHF Low 20V VHF High 0V UHF 4.5V


C41 1000P

3 BT 0.5~28V


C40 1000P

2 BM 4.5V


1 IF





EXPLODED VII



SCHEMATIC DIAGRAM FOR MODEL TR-1001S, TR-1001G







2. RESISTOR
 All resistors are carbon 1/4W resistor, unless otherwise noted the following marks.
 Unit of resistance is OHM (Ω). (K=1,000, M=1,000,000)
 (E): Non Flame resistor

3. CAPACITOR

All capacitors are ceramic 50V capacitor, unless of Unit of capacitance is μF, unless otherwise noted.

Polyester capacitor

Polyester capacitor

Transcolvation capacitor , unless otherwise noted the following marks. Polystyrene capacitor Tantal Electrolytic capacitor

Electrolytic capacitor

Unit of inductance is μH

TEST POINT

 $\begin{tabular}{ll} T.P. $\gamma:$ Test point-position. \\ \begin{tabular}{ll} VOLTAGE & MEASUREMENT \end{tabular}$

Voltage is measured by a volt ohm meter with DC

20K OHM/V receiving normal

easily found along with the direction of an arrow.

The of printing and subject to change without notice

REPLACEMENT PARTS LIST --- RESATZTEIL LISTE

- Note: 1. Main board (TNP81873-22H) is not available as a complete printed circuit board.
 - 2. The symbol marks (o) on the Replacement Parts List indicate chip parts.
 - 3. Tye symbol $\ensuremath{\mathbf{S}}$ is used in the schematic diagram and replacement parts list to indicate for safety resons, it is essential to use an approved replacement part.

- Bemerkung: 1. TNP81873-22H die gedruckte schaltung ist als komplet bestücket einheit lieferber.
 - 2. Das Symbol (o) auf der Ersatzteilliste steht für Chip-
 - Das Symbol **S** wird im Blockschaubild und in der Ersatzteilliste als Hinweis dafür, daß aus Sicherheitsgründen vorgeschriebene Teile verwendet werden müssen angegeben

			müssen angegeben.						
Ref. No.	Part No.	Description	Ref. No.	Part No.	Description				
	CABINET AND	MAIN CHASSIS PARTS		TXANQ11000P	Radio P.C.B. Complete				
	ONDINEET AND	MAIN CHAGGO LATTS		EAS2P01SH	Speaker				
			-	TSA800015	Rod Antenna				
				TSX8371B	Car Cord (TR-1001S Only)				
	TKY806003-2H	Upper Cabinet Complete	1	TSX8371-1B	Car Cord (TR-1001G Only)				
		Specific Complete	1		Sar Sera (TTT Too TS STITY)				
	TKY806103-1H	Bottom Cabinet Complete		TNQ8110	Clock				
		(TR-1001S Only)		TNQ8306	Antenna Matching Box $(75\Omega - 75\Omega)$				
	TKY806103-2H	Bottom Cabinet Complete	1 .	TY-AC35S	AC Adaptor (TR-1001S Only)				
	TKE011000 1	(TR-1001G Only)	-	TY-AC35G	AC Adaptor (TR-1001G Only)				
	TKE811903-1	Escutcheon Complete	VR51	EVLM3BT12A14	On-Off, Volume Control 10KΩA				
	TKC000667	Frank Bassass (Maria I.)	' ' ' ' '	EVENIODI IZALI	One on, volume control Tokaza				
	TKG809667	Front Protector (Window)	VR91	EVJLBAF01B15	Tuning Control 100K ΩB				
	TKK800242	Hand Clip	L1100	TLR80126	AM Bar Antenna				
	TKK800546-1	Lens Hood	1 - 100	TJB80919	i				
	TKK800716-1H	Front Protector		1	Battery Case				
	TKK804903	Accessory Bag		TJC80340	Battery Terminal (Clock)				
				TJ\$828281	Earphone Socket				
	TKK804904	Clock Adj. Stick		T 10000000					
	TKK809381-1	Dial Guide		TJS898200	C-A Plug (TR-1001S Only)				
	TKK809382-3	Dial Indication Plate		TJS898190	C-A Plug (TR-1001G Only)				
	TKK809428-1H	Set Leg	I	TXAJT2P003	2-P Mini. Connector Ass'y				
	TKK809542-2	Battery Cover		TV A ITABOO 4	(Earphone Socket)				
				TXAJT2P004	2-P Mini. Connector Ass'y (Volume Control)				
	TKK809546-1	Knob Barrier		TXAJT3P301	3-P Mini. Connector Ass'y				
	TKK809712	Battery Cover (Clock)		177731301	(Volume Control)				
	TKP8054521	Speaker Panel			(**************************************				
	TKX821102-1	TV Bracket		TXAJT4P132	4-P Mini. Connector Ass'y				
	TKX821201	Radio Bracket			(Tuning Control)				
				XEH15A2-B1	Earphone				
	TKZ800309	Picture Tube Bracket] .	XSS26+8BN	Cabinet Mounting Screw				
	TKZ800504	Set Leg Holder		XTN26+6B	Radio Bracket Mounting Screw				
	TUX80830	Set Leg Spring		XTN26+8B	Set Leg, TV Bracket Mounting Screw				
	TBM80098-1	Model Plate (TR-1001S Only)]		Set Log, 14 Bracket Woulding Screw				
	TBM80099-	Model Plate (TR-1001G Only)		XSN17+2	Radio Knob Mounting Screw				
		Woder Flate (TTI=10010 Offic)		XSN17+4	On-Off Volume Knob Mounting Screw				
•	TBX80674	On-Off Switch, Volume Knob		XSN26+4	Tuning Knob, Radio Pulley Mounting				
	TBX80675	TV/Radio Tuning Knob		73112014	Screw				
	TBX80676-1	Selector Switch Knob		XTN2+4B	On-Off Switch Control Mounting Scre				
	TBX80677-1	Control Knob		XUC5FT	Tuning Shaft Mounting Spring				
	TBX80810	Clock Button			James of the content				
	. 57.00010	CIOCK BULLOTT		TPC812841	Outer Carton (1 set) (TR-1001S Onl				
	TBX80811	Clock Mode Button		TPC812851	Outer Carton (1 set) (TR-1001G Onl				
1	TEK80474	Tention Roller (A)]	TPG801431	Outer Carbon (4 sets) (TR-1001S Onl				
	TEK80474	1		TPG801441	Outer Carbon (4 sets) (TR-10013 Onl				
	TEK80476	Tention Roller (B)		TXAPD11001S	Filler Complete				
	TEK80477	TV Pulley		TAALDITIOUIS	Timer Complete				
	1 - NOU4//	Radio Pulley		TOESESO	Sat Cover				
-	TEK90470	Tuning Chaft		TQE8580	Set Cover				
	TEK80478	Tuning Shaft		TOB811348	Fan Bag (TR-1001S Only)				
	TEK80479	Roller		TQB811349	Fan Bag (TR-1001G Only)				
	TEK80480	Roller Shaft		TQB810348	Instruction Book (TR-1001S Only)				
	TES8317	Radio Coil Spring	1	TQB810349	Instruction Book (TR-1001G Only)				
	TES8318	TV Coil Spring	1	TOD0111050	0.1-0.1/TD 10010.5				
	1000		1	TQD8111359	Sales Card (TR-1001S Only)				
	40CB4	Picture Tube	1 1	TQD8111360	Sales Card (TR-1001G Only)				
	TLY80601A	Deflection Yoke	1	TQD8111249	Power Cord Tag (TR-1001G Only)				
- 1	TNP81873-22H	Main P.C.B. Complete		TQD8118117	Warranty Card (TR-1001G Only)				
.	TNP81873H1Y	Clock P.C.B. Complete	.						
	TNP81873H1Z	Picture Tube Socket P.C.B. Complete	'	*					

Ref. No.	Part No.	Description	Ref.N	lo.	Part No.	D	escriptio	n ·	
	TN	P81873H1Z	C1307 C1304	0	ECKD1H681KB9 ECUX1H103MD	Ceramic Chip	680PF 0.01μF	±10% ±20%	50V 50V
0601	ECKD2H102KB2	Ceramic Capacitor	C1304			Chip		±20% ±10%	50 V
C601	ECKDŽI IOZNBZ	1000pF ±10% 500				L			
	RRD18XK152	Chip Resistor 1.5K ±10% 1/8 V	11			ESISTORS		0/	1/ 14/
	RRD18XK225	Chip Resistor 2.2M ±10% 1/8 V			RRD18XK102	Chip	1KΩ	±10%	1/ ₈ W 1/ ₈ W
R615 0 VR64	RRD18XK105 EVTK0CA00B26	Chip Resistor 1M $\pm 10\%$ $\frac{1}{8}$ V Focus Control 2M Ω B	R1302 R1303			Chip Chip	220KΩ 1MΩ	±10% ±10%	1/8 W
V 1104	LV I KOCAOOBZO	Todds Control Ziviazis	R1304			Chip	47KΩ	±10%	1/8 W
VR65	EVNK0BA00B55 TJ\$825050	Aux. Bright. Control 500KΩB Picture Tube Socket	R1305		· · · · · · ·	Chip	100ΚΩ	±10%	1/8 W
	CAR	CORD PARTS	R1306			Chip	10KΩ -680Ω	±10% ±10%	¹/ ₈ W ¹/ ₈ W
	XBA2F05NU100	Fuse	R1309 R1310		1	Chip Chip	100ΚΩ	±10%	1/8 W
	XBA1C05NS5	Fuse 0.5A (TR-1001G Only)	R1311			Chip	470ΚΩ	±10%	1/8 W
	TRF10SJ150	Non Flame Resistor 15Ω ±5% 10W	R1312		I .	Chip	330KΩ	±10%	1/8 W
	EYP2AS129	Temperature Fuse 129°C							*/
-	AC AD	APTOR PARTS	R1313	0	RRD18XK474	Chip	470ΚΩ	±10%	1/ ₈ W
	TKK819804-1H	AC Adaptor Upper Case Complete (TR-1001S Only)		_	TNF	P81873-22H	1		
	TKK819804-2H	AC Adaptor Upper Case Complete (TR-1001G Only)				TUNER	-	_ 	
	TKK819805 TBM80122	AC Adaptor Bottom Case AC Adaptor Model Plate		_	TNV77101F1	U/V Combo.	Tuner		
		(TR-1001S Only)		IC					
	TBM80123	AC Adaptor Model Plate (TR-1001G Only)	IC11		AN5710	J V-IF Amp./A	.GC		
		(111 10012 0111)	IC12		AN5720	V-IF Det./Vio			
	TLP81250W	Power Trans.	IC21		AN5730	S-IF Amp./De			
	TSX8178	AC Cord (TR-1001S Only)	IC31		AN5760	Vert. Osc./Ar			- Drive
	TSX8179	AC Cord (TR-1001G Only)	IC41		AN5750	Sync. Sep. Ar	np./Horiz A	APC. Ost	J. Drive
	TSX8925 TSE80135	DC Cord With 1-P Plug Power Selector Switch	IC42		TVSMPC574J	Zener			
	19580133	Power Selector Switch	IC51		TVSBA526	Audio			
	TMM81608	Cord Bushing (AC)	IC91		AN5700	Channel Selec	ctor		
	TMM81609	Cord Bushing (DC)			TRA	ANSISTORS			
	XBA2C080TR0 TJC3316	Fuse 80mA 250 Fuse Holder	V Q14	0		Video Output	t		
	SVB10-100NCA	Power Rectifier	Q44	S	1	Horiz Outpu			
	37010100100	1 dwel freetines	∏ Q71	0	2SD601	AVR			
	ECKD1H103PF2	Ceramic Capacitor	Q72	0	202.00	AVR			
		0.01μF ± 000 % 50 V	Q73	0	2SB743	AVR		,	
	ECEA1CV172Z	Electrolytic Capacitor 1700µF 16V	074	0	200601	AVR			
<u> </u>		[,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,	Q74 Q91	0		Switching			
	TAII	P81873H1Y	Q92	0	2SD601A	Switching			
	1 103		_			DIODES			
		IC	D15	0	MA151K	Video			
IC301	TVSMPD4011C	Nand Gate	D22	0		Switching			:
	DI	ESISTORS	D23	0	1117 101	Switching			
Q301 °	2SD601	Switching	D24	0	MA57	Switching			
Q302 °		Switching	D25	0	MA57	Switching			a
Q303 °	2SD601	Switching	D26	0	MA57	Switching			
Q304 °	2SB709	Switching	D27	0		Switching			
	<u></u>	NODEC	D28	0		Switching			
D004		DIODES	D31	0	MA151K	Switching			
	MA151K MA151K	Switching	D38	0	MA151K	Blanking			
	MA151K MA151K	Switching Switching	D41	اہ	MA151K	Pulse Clipper			
			D41	0	TVS08V-100	Pulse Clipper Damper			
	CA	PACITORS	D43	0		Rectifier			
C1301	ECEA1HK010EJ	Electrolytic 1µF 50V	D45	0	MA152K	Rectifier			
C1302	ECEA1EK4R7EJ	Electrolytic 4.7μ F 25 V	D46	S	TVSBB10	Rectifier			
C1303 C1306	ECEA1EK4R7EJ ECKD1H271KB	Electrolytic 4.7μ F $25V$ Ceramic $270PF \pm 10\% 50V$	11						
J 1300	-CVD1U7/1KB	Coranno 270FF =10% 50V							

Ref.N	lo.	Part No.	Des	scriptio	n		Ref. N	o.	Part No.	De	escriptio	n	
D47		TVSRD4R7EB	Zener				C307	0	ECUX1H102MD	Chip	1000pF	±20%	50V
D75		TVSRD3R3EB	Zener				C308		ECEA0JK330	Electrolytic	33 µ F		6.3V
D76	0	MA151K	Switching				C309		ECEA0JV471W	Electrolytic	470µF		6.3V
D77		TVSRD7R5JB	Zener				C311		ECEA1AS101SW	Electrolytic	100µF		10V
D91	0	MA151K	Switching				C312		ECEA0JV471W	Electrolytic	470µF		6.3V
		MA151WK					C361	0	ECUX1H103MD	Chip	0.01 μ F	±20%	50V
D92	0		Switching				C362	0	ECUX1H181K	Chip	180pF		50V
		COILS &	TRANSFORM	IERS			C401	0	ECUX1H333ZF	Chip		+80 % -20 %	50V
L101		TLI801358	V-IF Trans.				C402		ECEA1HK010EJ	Electrolytic	1μF 100pF	+1.00/	50V
L131		TLQ391K146C	Peaking Coil				C403	0	ECUX1H101K	Chip	TOOPE	±10%	50V
L132		TLQ391K146C	Peaking Coil				0404	_	FOUNT 11470MD	Ch:n	4700pF	+200/	50V
L202		TLQ100K146	Peaking Coil				C404	0	ECUX1H472MD ECUX1H153MD	Chip Chip	0.015µF		50V
L301		TLQ391K146C	Peaking Coil				C405	0		Chip	0.015µF		50V
	_						C407 C408	U	ECUX1H153MD ECEA1CK100	Electrolytic	0.015μF 10μF	±2070	16V
T401	8	TLF80957	Flyback Trans.				C408		ECSZ10EF22N	Tantalum	10μF 22μF		10V
		CA	APACITORS			~	C409		LC3210L1 2211	Tantalum	22,41		100
C91	0	ECUX1H103ZF	Chip	0.01 <i>µ</i> F	+80% -20%	50V	C410	0	ECUX1H153ZF	Chip	0.015µF	+80% -20%	50V
C92	0	ECUX1H103ZF	Chip	$0.01 \mu F$	+80%	50V	C411		ECQK1103JZ	Polyestel Poly			
C93	0	ECUX1H103ZF	Chip	0.01µF	+80% -20%	50V	1			1	0.01µF	±5%	100V
C94	0	ECUX1H103ZF	Chip	$0.01 \mu F$	+80 %	50V	C413		ECEA1HK010EJ	Electrolytic	1μF		50V
C95	0	ECUX1H103ZF	Chip	0.01µF	+80% -20%	50V	C414		ECQM2103KZ	Polyester	0.01µF		200V
							C415	0	ECUX1H102MD	Chip	1,000pF	±20%	50V
C96	0	ECUX1H103ZF	Chip	0.01µF	+80 % -20 %	50V	C418		ECEA0JV221W	Electrolytic	220µF	180	6.3V
C97	0	ECUX1H103ZF	Chip	0.01µF	+80 %	50V	C416	0	ECUX1H333ZF	Chip	$0.033 \mu F$	+80% -20%	50V
C98	0	ECUX1H103ZF	Chip	0.01µF	+80% -20%	50V	C417	0	ECUX1H222MD	Chip	2200pF	±20%	50V
C101	0	ECUX1H103ZF	Chip	0.01µF	+80 %	50V	C440	0	ECUX1H333ZF	Chip	$0.033 \mu F$	+80%	50V
C102	0	ECUX1H103ZF	Chip	0.01µF	+80 %	50V	C441		ECKD2H391KB9	Ceramic	390pF	±10%	500V
							C442		ECEA2AS3R3	Electrolytic	3.3 µ F		100V
C103	0	ECUX1H103ZF	Chip	0.01µF	+80 %	50V	C443		ECKC3A182MD	Ceramic	1800pF	+20%	5KV
C105	0	ECUX1H103ZF	Chip	0.01µF	+80 %	50V	C443		ECEA1CK100	Electrolytic	1000μF	±2070	16V
C106	0	ECUX1H103ZF	Chip	0.01µF	+80 % -20 %	50V	C445	0	ECUX1H333ZF	Chip	0.033µF	+80 %	50V
C131		ECEA0JV471W	Electrolytic	470µF		6.3V	C501	O	ECSF1VM473	Tantalum	0.033µ1 0.047µF	-20 70	35V
C132	0	ECUX1H103ZF	Chip	0.01 <i>µ</i> F	+80 % -20 %	50V	C501	0	ECUX1H152MD	Chip	1.500pF	±20%	50V
C133		ECSZ10EF22N	Tantalum	22 µ F		10V							
C134	0	ECUX1H103ZF	Chip	0.01µF	+80 %	50V	C503		ECEA0JV221W	Electrolytic	220µF		6.3V
C140		ECEA1EK4R7EJ	Electrolytic	4.7μF		25V	C504		ECEA0JK220EJ	Electrolytic	22 µ F		6.3V
C141		ECEA0JK101	Electrolytic	100µF		6.3V	C505		ECEA1CK100	Electrolytic	10 µ F		16V
C142	0	ECUX1H102MD	Chip	1000pF	±20%	50V	C506		ECEA1CK100	Electrolytic	10μF		16V
0140	0	ECHV1H2227E	Chin	0.033µF	+800/	50V	C507		ECEA0JK470	Electrolytic	47 μ F		6.3V
C143 C144	0	ECUX1H333ZF ECUX1H333ZF		0.033µF	-20 /0 +80 % -20 %	50V	C508		ECSF1VM473	Tantalum	$0.047 \mu F$		35V
C144	0	ECUX1H471MD	Chip	470pF		50V	C701		ECEA1CV101W	Electrolytic	100µF		16V
C143		ECEAOJK 101	Electrolytic	100μF	-2070	6.3V	C702	0	ECUX1H101K	Chip	100pF	±10%	50V
C183		ECSF1AM475C	Tantalum	4.7μF		10V	C703		ECEA0JV471W	Electrolytic	470 µ F		6.3V
0100		2001 7/1014700	Turranam				C704A		ECEA1EK4R7EJ	Electrolytic	4.7µF		25V
C184	0	ECUX1H102MD	Chip	1000pF		50V	C705		ECEA1AS101	Electrolytic	100μF		10V
C205	0	ECUX1H153MD		0.015µF		50V	C705	0	ECUX1H153MD	Chip	0.015µF	+20%	50V
C207	0	ECUX1H333ZF		0.033µF	-20%	50V	2700		ECOX H H DOWN	Cilib	υ.υιυμι	-20/0	
C208		ECEA0JK101	Electrolytic	100μF		6.3V			RI	ESISTORS			
C209	0	ECUX1H103ZF	Chip	0.01µF	-20%	50V	R91	0	RRD18XK682	Chip	6.8K Ω	±10%	1/8W
C210	0	ECUX1H103ZF	Chip	0.01µF	+80 % -20 %	50V	R92	0	RRD18XK102	Chip	1ΚΩ	±10%	1/8W
C210	0	ECUX1H103ZF	Chip	0.01µF		50V	R93	0	RRD18XK274	Chip	270 K Ω	±10%	1/8W
C211	0	ECUX1H103ZF	Chip	0.01µF		50V	R94	0	RRD18XK223	Chip	22 K Ω	±10%	1/8W
C212	0	ECUX1H390KC	Chip		±10%	50V	R95	0	RRD18XK822	Chip	8.2 K Ω	±10%	1/8W
C301	0	ECUX1H103MD	Chip	0.01µF		50V							11.
-				•			R96	0	RRD18XK105	Chip	1ΜΩ	±10%	1/8W
C302	0	ECUX1H153MD	Chip	0.015 µ F	±20%	50V	R97	0	RRD18XK103	Chip	10ΚΩ	±10%	1/8W
C303		ECEA1HK010EJ	Electrolytic	1 μ F		50V	R98	0	RRD18XK103	Chip	10KΩ	±10%	1/8W
C304		ECSF1VM334C	Tantalum	0.33 µ F		35V ⁻	R101	0	RRD18XK560	Chip	56Ω	±10%	1/8W
C305		ECSF1AM475C	Tantalum	4.7 μ F		10V	R111	Ó	RRD18XK182	Chip	1.8 K Ω	±10%	1/8 W
C306		ECSF1AM225C	Tantalum	2.2µF		10V							
		1	1						<u> </u>				

Ref. No.	Part No. Description			Ref. No. Part No.		Description			
D144	DDD40VK404	Ohin 400K	+1.00/ 1/14/	R601 ∘	DDD10VV105	Chip 1MO 1400/ 1/14			
R141 o	RRD18XK104	Chip 100KΩ	±10% ¹ / ₈ W		RRD18XK105	Chip $1M\Omega \pm 10\% \frac{1}{8}W$ Chip $390\Omega \pm 10\% \frac{1}{8}W$			
R142 o	RRD18XK103	Chip 10KΩ	±10% ¹ / ₈ W	R701 0	RRD18XK391	1 1			
R143 o	RRD18XK153	Chip 15KΩ	±10% ¹ / ₈ W	R702 0	RRD18XK682	Chip $6.8K\Omega \pm 10\%$ $\frac{1}{8}W$			
R144 o	RRD18XK102	Chip 1KΩ	±10% ¹ / ₈ W	R703 o	RRD18XK472	Chip $4.7K\Omega \pm 10\% \frac{1}{8}W$			
R145 o	RRD18XK331	Chip 330 Ω	±10% ¹ / ₈ W	R704 o	RRD18XK471	Chip $470\Omega \pm 10\%$ $\frac{1}{8}$ W			
R180 o	RRD18XK122	Chip 1.2KΩ	±10% ¹ / ₈ W	R705 °	RRD18XK472	Chip $4.7 \text{K}\Omega \pm 10\% ^{1}/_{8} \text{W}$			
R181 o	RRD18XK183	Chip $18K\Omega$	±10% ¹ / ₈ W	R708	ERD10TJ101	Carbon $100\Omega \pm 5\%$ $\frac{1}{8}W$			
R182 o	RRD18XK224	Chip $220K\Omega$	±10% ½W	R710 ○	RRD18XK391	Chip $390\Omega \pm 10\% \frac{1}{8}W$			
R183 o	RRD18XK183	Chip $18K\Omega$	±10% ¹ / ₈ W	R711 °	RRD18XK391	Chip $390\Omega \pm 10\% \frac{1}{8}W$			
R184 o	RRD18XK102	Chip $1K\Omega$	±10% ¹ / ₈ W	R712 °	RRD18XK391	Chip $390\Omega \pm 10\% \frac{1}{8}W$			
				D710 0	DDD10VK001	Ohio 2000 110% 1/ W			
R185 o	RRD18XK152	Chip 1.5KΩ	±10% ¹ / ₈ W	R713 0	RRD18XK391	Chip 390Ω ±10% ½W			
R186 0	RRD18XK331	Chip 330Ω	±10% ¹ / ₈ W		RRD18XK391	Chip $390\Omega \pm 10\%$ $\frac{1}{8}$ W			
R187 o	RRD18XK332	Chip 3.3KΩ	±10% ¹ / ₈ W	R715 °	RRD18XK391	Chip $390\Omega \pm 10\%$ $\frac{1}{8}$ W			
R188 o	RRD18XK273	Chip 27KΩ	±10% ¹ / ₈ W	R716 °	RRD18XK391	Chip $390\Omega \pm 10\%$ $\frac{1}{8}$ W			
R201 o	RRD18XK101	Chip 100Ω	±10% ¹ / ₈ W	R717 °	RRD18XK391	Chip $390\Omega \pm 10\% \frac{1}{8}W$			
R202 o	RRD18XK562	Chip 5.6 K Ω	±10% ½W		CEF	RAPS			
R203 o	RRD18XK562	Chip 5.6KΩ	±10% 1/8W	CF21	EFCS4R5MCM	S-IF Input Filter			
R204 o	RRD18XK562	Chip $5.6K\Omega$	±10% 1/8W	CF22	EFCS5R5MCM	S-IF Input Filter			
R206 o	RRD18XK123	Chip 12K Ω	±10% ¹ / ₈ W	CF23	EFCS6ROMCM	S-IF Input Filter			
R207 0	RRD18XK123	Chip $12K\Omega$	±10% ½W	CF25	EFCS4R5MSM	Discriminator			
11207	TITIBTOAKTZO	72112	1070 /811	CF26	EFCS5R5MSM	Discriminator			
R208 o	RRD18XK123	Chip 12KΩ	±10% ¹ / ₈ W						
R212 o	RRD18XK272	Chip 2.7,KΩ	±10% 1/8W	CF27	EFCS6R0MSM	Discriminator			
R213 o	RRD18XK330	Chip 33Ω	±10% ¹ / ₈ W						
R301 o	RRD18XK153	Chip 15KΩ	±10% ½W		1	NTROLS			
R302 o	RRD18XK183	Chip 18KΩ	±10% ½W	VR19	EVNK0BA00B53	RF AGC 5KΩB			
			7.5	VR31	EVLV0FA00B15	Vert. Hold 100KΩB			
R303 o	RRD18XK683	Chip 68KΩ	±10% ¹ / ₈ W	VR32	EVNA1AA00B54	Vert. Height 50KΩB			
R304 o	RRD18XK184	Chip 180KΩ	±10% ¹ / ₈ W	VR41	EVNJ0BA00B13	Horiz. Freq. 1KΩB			
R305 o	RRD18XK183	Chip 18KΩ	±10% ½W	VR62	EVJ7KA30923X	Contrast 2K Ω X			
R306 o	RRD18XK392	Chip 3.9KΩ	±10% ½W		, ·				
R307 o	RRD18XK332	Chip 3.3KΩ	±10% ½W	VR63	EVLV0FA00B55	Bright. 500KΩB			
111007	1111B16/11002	0.0122	21070 /811	VR7.1	EVNA6AA00B23	AVR 2KΩB			
R308 o	RRD18XK682	Chip 6.8 K Ω	±10% ¹ / ₈ W	VR92	EVNA1AA00B54	Sub Tuning 50KΩB			
R309 o	RRD18XK472	Chip $4.7K\Omega$	±10% ½W	VR93	EVNA1AA00B54	Sub Tuning 50KΩB			
R310 o	RRD18XK2R7	Chip 2.7Ω	±10% ½W	VR94	EVNA1AA00B25	Sub Tuning 200KΩB			
R313 o	RRD18XK391	Chip 390Ω	±10% ¹ / ₈ W						
R360 o	RRD18XK821	Chip 820Ω	±10% ½W	VR95	EVNA1AA00B54	Sub Tuning 50KΩB			
					OTHER PARTS				
R361 °	RRD18XK563	Chip 56KΩ	±10% ½W		OTHER PARTS TJC80337 Battery Terminal				
R401 °	RRD18XK561	Chip 560Ω	±10% ¹ / ₈ W	÷	TJS828290	DC Socket			
R402 °	RRD18XK390	Chip 39Ω	±10% ¹ / ₈ W	· ·	TJS868260	4-P Mini, Connector Plug			
R403 °	RRD18XK103	Chip 10KΩ	±10% ¹ / ₈ W		TJS868420 4-P Mini, Connector Plug				
R404 °	RRD18XK222	Chip 2.2KΩ	±10% ¹ / ₈ W		. 55555				
R405 o	RRD18XK273	Chip $27K\Omega$	±10% ¹ / ₈ W		TJS868430	3-P Mini. Connector Plug			
R406 0	RRD18XK470	Chip 47Ω	±10% /8VV ±10% ¹ / ₈ W		TXAJT5P060	5-P Mini, Connector Ass'y			
R407 °	RRD18XK272	Chip $2.7K\Omega$	±10% /8W	SW1	TSE80330	TV/FM/AM Selector Switch			
R407 0	RRD18XK471	Chip 2.7 N_{32}	±10% / ₈ W	SW2	TSE80329	A/E/G Formula Selector Switch			
R409 0	RRD18XK474	Chip 470 S	±10% / ₈ W ±10% ¹ / ₈ W	SW4	TSE80329	U/V Selector Switch			
				1					
R440 0	RRD18XK392	Chip 3.9KΩ	±10% ½W						
R441 0	RRD18XK334	Chip 330KΩ	±10% ½W		TNIDO	2983-21			
R442 o	RRD18XK394	Chip 390KΩ	±10% ½W		LINEQ				
R443 o	RRD18XK105	Chip $1M\Omega$	±10% ½W		<u> </u>	C			
R444 o	RRD18XK472	Chip 4.7 K Ω	±10% ¹ / ₈ W	10101		FM Front End			
D445		Chin	1100/ 1/ 14/	IC101 IC102	AN7213 AN7218	AM RF, IF/FM IF			
R445 0	RRD18XK102	Chip 1KΩ	±10% ½W	10102	, 4147 Z T O	/ MV (11 / 11 / 1 W 11			
R502 o	RRD18XK680	Chip 68Ω	±10% ½W		TRAN	SISTORS			
	ERD25FJ390	Carbon 39Ω	±5% ¼W	Q101 o	2SC1009	FM IF Amp. (F3, F4)			
R504 o	RRD18XK221	Chip 220Ω	±10% ½W	Q110 0	2SK160	AM RF Amp. (K5, K6)			
R505 o	RRD18XK473	Chip 47KΩ	±10% ¹ / ₈ W		251(100	, , ,			
				L					

Ref. No.	Part No.	Description			Ref. No.		Part No.	Description				
	DIODES									•		
D80 o	MA57	Switching				C1134		ECEA1CK100	Electrolytic	10 μ F	1 8 A	16V
D81	TVS1SV80	Switching				C1135	O	ECUX1H103ZF	Chip	0.01 µ F	-20%	50V
D82 o	MA57	Switching				C1136	0	ECUX1H102MD	Chip	1000pF	+20%	50V
D102	OA91	FM Det.				C1137		ECUX1H103ZF	Chip	0.01µF		50V
D103	OA91	FM Det.				C1138		ECSF35ER1	Tantalum	0.01 µ F	-20 /0	35V
D106 o	MA151WK	Switching				C1139	0	ECUX1H333ZF	Chip	0.033µF	+80 %	50V
D110	OA91	AM Det.						Į ·				
	COILS & TRANSFORMERS						RES	ISTORS				
		1				R81	0	RRD18XK102	Chip	1ΚΩ	±10%	1/8W
L80 L81	TLR809493C TLR80127	RF Choke Coi	1			R82	0	RRD18XK222	Chip	2.2ΚΩ	±10%	1/8W
L1003	TLR809455C	Loading Coil Loading Coil				R83	0	RRD18XK474	Chip	470K Ω	±10%	1/8W
L1004	TLR809445C	FM RF Coil				R84	Ó	RRD18XK474	Chip	470 K Ω	±10%	$\frac{1}{8}$ W
L1005	TLR809454C	FM Osc. Coil				R85	0	RRD18XK474	Chip	470K Ω	±10%	1/8W
								55546748474				1/
L1006	EIF7S803A	FM IF Trans.				R86 R1001	0	RRD18XK474	Chip	470KΩ	±10%	1/8W
L1007	EIF7S804D	FM Det. Coil				R1001		RRD18XK470 RRD18XK680	Chip Chip	47Ω 68Ω	±10% ±10%	¹/ ₈ W ¹/ ₈ W
L1008	EIF7S801E	FM Det. Coil				R1002		RRD18XK101	Chip	08Ω 100Ω	±10%	1/ ₈ W
L1101	ELL7S801A	AM Osc. Coil				R1004		RRD18XK393	Chip	39KΩ	±10%	1/8 W
L1110	EIA7S802A	AM IF Trans.								50.132	- 1070	/8 4 A
L1111	EIA7S808D	AM Det. Coil				R1005	0	RRD18XK470	Chip	47Ω	±10%	$\frac{1}{8}$ W
	EIA73000D	AW Det. Coll				R1050	0	RRD18XK334	Chip	330K Ω	±10%	1/8 W
	CAPA	CITORS				R1051	Į	RRD18XK102	Chip	1ΚΩ	±10%	¹/ ₈ ₩
C80 °	ECUX1H102MD	Chip	1000pF	±20%	50V	R1052		RRD18XK102	Chip	1KΩ	±10%	$\frac{1}{8}$ W
C81 °	ECUX1H103ZF	Chip	0.01µF		50V	R1053	0	RRD18XK331	Chip	330Ω	±10%	$^{1}/_{8}W$
C1001	PVCLC416-1	Poly. Variable				R1054		DDD10VK601	CI-:-	0000		1/
	ECUX1H103ZF	Chip	0.01µF		50V	R1054	- 1	RRD18XK681 RRD18XK331	Chip Chip	Ω 086	±10% ±10%	1/8W
C1005 °	ECUX1H333ZF	Chip	0.033 µ F	+80% -20%	50V	R1056		RRD18XK102	Chip	330 32 1ΚΩ	±10%	¹/ ₈ W ¹/ ₈ W
C1006 °	ECHY111100KC	Ola fa	40 =			R1057		RRD18XK102	Chip	1ΚΩ	±10%	1/8 W
	ECUX1H180KC ECUX1H103ZF	Chip Chip		±10% +80%	50V	R1058	0	RRD18XK103	Chip	10ΚΩ	±10%	1/8 W
	ECUX1H103ZF	Chip	0.01μF 0.01μF		50∨ 50∨							
I	ECUX1H050DC	Chip		±0.5pF		R1059	- 1	RRD18XK153	Chip	15K Ω	±10%	$^{1}/_{8}W$
I	ECUX1H150KC	Chip		±10%	50V	R1060	- 1	RRD18XK333	Chip	33K Ω	±10%	¹∕ ₈ W
					•••	R1061 R1062		RRD18xk470	Chip	47Ω	±10%	1/8W
C1012 0	ECUX1H220KC	Chip	22pF	±10%	50V	R11002	- 1	RRD18XK222 RRD18XK101	Chip Chip	2.2KΩ 100Ω	±10%	¹/ ₈ ₩
	ECUX1H103ZF	Chip	0.01 µ F	+80% -20%	50V	111100		HIDTOXXIO	Cinp	10022	±10%	¹/ ₈ ₩
	ECUX1H103ZF	Chip	0.01μ F	+80%	50V	R1101		RRD18XK102	Chip	1ΚΩ	±10%	1/8W
	ECUX1H103ZF	Chip	0.01 µ F	+80% -20%	50V	R1102		RRD18XK684	Chip	680KΩ	±10%	1/8 W
C1050 0	ECUX1H103ZF	Chip	0.01 µ F	-20%	50V	R1130	0	RRD18XK102	Chip	1ΚΩ	±10%	50V
C1051 o	ECUX1H103ZF	Chip	0.01 µ F	+800/	50V	R1131	0	RRD18XK103	Chip	10KΩ	±10%	50V
	ECUX1H103ZF	Chip	0.01 μ F		50V	R1132	0	RRD18XK473	Chip	47 K Ω	±10%	50∨
	ECUX1H103ZF	Chip	0.01µF		50V							
I .	ECUX1H333ZF	Chip	0.033 µ F		50V	R1133	- 1	RRD18XK103	Chip	10KΩ	±10%	50∨
C1056	ECEA1ES4R7	Electrolytic	4.7 µ F		25V	R1134		RRD18XK101	Chip	100Ω	±10%	50V
						R1135 R1136		RRD18XK103 RRD18XK183	Chip Chip	10Κ Ω 18Κ Ω	±10%	50V
1	ECUX1H103ZF	Chip	0.01 µ F	+80 -20%	50V	R1137		RRD18XK333	Chip	33KΩ	±10% ±10%	50V 50V
	ECEA1CK100	Electrolytic	10µF		16V		٦		CITIP	JUN 34	-10%	50 V
i i	ECUX1H472MD	Chip	4700pF	±20%	50V	R1138	0	RRD18XK471	Chip	470Ω	±10%	50V
		Electrolytic Chip	10μF 0.01μF	+800/	16V	J1011		RRD18XK000	Chip	0Ω	570	
2,001	LOOK HITOSEF	Crit	υ.υ ιμΓ	-20%	50V	J1012		RRD18XK000	Chip	Ω 0		
C1101 0 I	ECUX1H100KC	Chip	10pF	±10%	50V	J1013		RRD18XK000	Chip	Ω 0		1
I .	I	Chip		+80%	50V			<u> </u>				
I .	and the second second	Chip	0.01 µ F		50V	05.5		i	RPARTS			ļ
	ECUX1H103ZF	Chip	0.01 µ F		50V	CF101		TFCS10R7M-2	10.7MHz Filter			ſ
C1105 0 E	ECUX1H050DC	Chip		±0.5pF		CF102 CF110	- 1	TFCS10R7M-2	10.7MHz Filter	r ,		
01101	505116:::::					H	- 1	RVFCFM2455E RXABPMB1	Filter FM BPF.			.
	1	Electrolytic	10μF		16V	2101	- 1	TJS828300	Ext. Antenna S	Socket		
		Electrolytic	10 µ F		16V	1			-at. Antonna c	JOCKEL		.]
5,100	-CEATCRIOU	Electrolytic	10 μ F		16V			TJS868550	5-P L-Type Mir	ni. Connect	tor Plua	ŀ
	<u> </u>			·					- · - · / PO WIII		rug	